# 5/16 IN. Multi-Ply Structural Screws STRUCTURAL MULTI-PLY ASSEMBLIES



5/16" T-40 Star Multi-Ply Screw PROTECH® Ultra 4 coated

CAMO 5/16" Structural Multi-Ply and Ledger + Multi-Ply Screws have been evaluated for their ability to provide multi-ply attachment in trusses, sawn lumber and engineered wood products / structural composite lumber (SCL) applications. When installed following the instructions in this bulletin, the use of our 5/16" structural screws is governed by the applicable code and the provisions for dowel type fasteners in the National Design Specification (NDS) for Wood Construction to replace nails or bolts.

### **CORROSION STATEMENT**

Our proprietary PROTECH Ultra 4 four-layer coating system applied to our Multi-Ply Screws has been tested in accordance with ASTM G198 and offers the same level of protection as code-approved hot-dip galvanized (ASTM A153, Class D) in ground contact general use pressure treated lumber (AWPA UC1-UC4A). Our Multi-Ply screws with PROTECH Ultra 4 coating are recognized for use in untreated lumber, ground contact general use pressure-treated lumber, and fire retardant treated (FRT) lumber. A statement of compliance can be found in our DrJ TER reports.

### **PRODUCT FEATURES**

- Code listed per DrJ TER No. 2102-01 and 2102-04 and State of Florida FL 41741
- Flat head with T-40 star drive
- No pre-drilling necessary
- PROTECH Ultra 4 coating offers same level of protection as hot-dip galvanized coating
- Head markings provide easy identification after installation





### SAWN LUMBER MULTI-PLY ASSEMBLIES

### **INSTALLATION INSTRUCTIONS - SAWN LUMBER**

- 1) Choose the proper fastener length for your Sawn Lumber application (Table 1)
- 2) Use a ½" (12.7mm) low rpm/high torque electric drill (450 rpm) and the driver bit supplied with the screws.
- 3) Install fasteners in rows (staggered or in-line) per Table 1. Follow the minimum spacing, edge distance, and end distance requirements in Table 3.
- 4) Drive the screws until the underside of the head is flush to the surface of the wood. Do not overdrive.




TABLE 1: Allowable Lateral Design Values (plf) for Multi-Ply Truss and Sawn Lumber Assemblies <sup>23,4,5,6</sup>

f


NATIONAL

## STRUCTURAL COMPOSITE LUMBER MULTI-PLY ASSEMBLIES

#### **INSTALLATION INSTRUCTIONS - STRUCTURAL COMPOSITE LUMBER**

- 1) Choose the proper fastener length for your Structural Composite Lumber application (Table 2)
- 2) Use a ½" (12.7mm) low rpm/high torque electric drill (450 rpm) and the driver bit supplied with the screws.
- 3) Install fasteners in either 2 or 3 rows (staggered or in-line) per Table 2. Follow the minimum spacing requirements in Table 3.
- 4) Drive the screws until the underside of the head is flush to the surface of the wood. Do not overdrive.

TABLE 2: Allowable Lateral Design Values (plf) for Multi-Ply Truss and SCL Assemblies<sup>2,3,4,5,6</sup>



4. The tabulated allowable design loads may be applies to either side of the beam (head or point side of the fastener). Where loads are applied to both sides of the beam simultaneously, the total load applied to the beam shall not exceed the tabulated load.

5. For top-loaded members with even loading across the width of the entire assembly, and a depth of 18" or less, fasteners shall be installed in two (2) rows with a maximum distance of 24" o.c. between fasteners in the same row. Use three (3) rows for members deeper than 18".

6. Tabulated loads are for the connection strength. Beams and framing members shall be independently checked by a registered design professional.

### MINIMUM SPACING REQUIREMENTS

TABLE 3: Screw Spacing, Edge Distance, and End Distance Requirements<sup>1,2</sup>

	MINIMUM SPACING (IN)				
	3 %"				
	2 ¼"				
	2 ¼"				
•	5/8"				
9	3 1/8"				
	2 ¼"				
•	1%"				
U U	5%"				
	$\oplus$				

2. Values for "Spacing between Rows or Fasteners-Staggered" apply where the screws in adjacent rows are offset by one-half of the "Spacing between Fasteners in a Row".

TABLE 4: CAMO® 5/16" Structural Series Screws Properties<sup>1</sup>

FASTENER DESIGNATION	HEAD			LENGTH (IN)		DIAMETER (IN)			BENDING YIELD STRENGTH⁴	Allowable Steel Strengths (Ibs)		
	STYLE	DRIVE SYSTEM	DIAMETER	HEIGHT	<b>FASTENER</b> <sup>2</sup>	<b>THREAD</b> <sup>3</sup>	SHANK	MINOR	MAJOR	fyb (psi)	TENSILE	SHEAR⁵
5⁄16" X 2 7⁄8"	- Flat Head	t Head T40 Star Drive	.738	.079	2.875	1.437	.220	.197	.307	175,000	1,580	1,150
5⁄16" X 3 ½"					3.500	2.000						
⁵⁄16" X 4"					4.000	2.370						
5%6" X 4 ½"					4.500	2.370						
⁵⁄16 <b>" X 5"</b>					5.000	2.752						
<sup>5</sup> ⁄16" X 6"					6.000	2.752						
<sup>5</sup> /16" X 6 <sup>3</sup> /4"					6.750	2.752						

SI: 1 in = 25.4 mm, 1 lb = 4.45 N, 1 psi = 0.00689 MPa

1. Tabulated fastener dimensions are measured on uncoated fasteners. Finished dimensions are different due to the proprietary coating added.

2. Nominal fastener length is measured from the underside of the head to the tip.

3. Thread length includes tapered tip.

4. Bending yield strength, Fyb, is determined in accordance with ASTM FI575 using minor thread diameter when fastener is tested in threa ded section.

5. Shear strength is determined in accordance with AISI S904 using minor thread diameter when fastener is tested in threaded section.

f